



Part# 161302X

Can Am Defender Grill



Installation Instructions

1. To gain access to the grille pull forward on the hood and pick straight up.



2. Remove two (2) plastic push pins and pull factory grille up and out.



3. To install 360 grille, slide tabs into pockets. Replace factory push pins.



Proudly Made In America

Technical questions (903) 935-1980